




## Clavadora neumática simC32 | Pneumatic nailer simC32

### Explosionado - Exploded view



simC32

1205232

### Despiece - Spare part list

| COD.    | DESC.              |
|---------|--------------------|
| CA1601  | DOOR LATCH         |
| CA2001  | GROMMET            |
| CB2201  | COMPRESSION SPRING |
| CC1501  | SPRING RECEIVER    |
| CC1901  | BUSHING            |
| CC2601  | PIN                |
| CD0801  | FEED PISTON CAP    |
| CD2101  | SPRING RECEIVER    |
| CD3201  | COMPRESSION SPRING |
| CD3301  | COMPRESSION SPRING |
| CG3301  | SCREW RING         |
| CJ0201  | CYLINDER CAP       |
| CJ0301  | CAP SEAL           |
| CJ0901  | FEED PISTON CAP    |
| CJ1701  | CANISTER COVER     |
| CJ1801  | PIN                |
| CK1501  | FIXED SEAT         |
| CK1601  | PULL SPRING        |
| CK3401  | SAFETY             |
| CL0101  | BODY               |
| CL0201  | DRIVER             |
| CL0301  | NOSE               |
| CL0301W | DRIVER ASSY.       |
| CL0401  | FEED PAWL          |
| CL0501  | DOOR               |
| CL0601  | CANISTER           |
| CL0701  | HOLDING PAWL       |
| CL0801  | PIN                |
| CL0901  | PIN                |
| CL1001  | SAFETY             |

| COD.   | DESC.              |
|--------|--------------------|
| CL1201 | SAFETY SET         |
| CL1301 | DUST SHIELD        |
| CL1401 | TRIP COVER         |
| CL1501 | PISTON BUMPER      |
| CL1601 | SPRING             |
| CL1701 | CYLINDER           |
| CL1801 | MAIN PISTON        |
| CL1901 | CYLINDER RING      |
| CL2001 | HEAD VALVE PISTON  |
| CL2201 | BUSHING            |
| FA4401 | EXHAUST CAP        |
| FA4801 | BUMPER             |
| FA4901 | COLLAR             |
| FB2401 | COMPRESSION SPRING |
| FB2501 | PISTON STOP        |
| FB3801 | PISTON STOP        |
| FE1201 | EXHAUST CAP RING   |
| FK1601 | C-RING             |
| FK2201 | COMPRESSION SPRING |
| KF0510 | FLAT HD.BOLT       |
| KM0410 | HEX.SOC.HD.BOLT    |
| KM0514 | HEX.SOC.HD.BOLT    |
| KM0522 | HEX.SOC.HD.BOLT    |
| KM0527 | HEX.SOC.HD.BOLT    |
| KM0530 | HEX.SOC.HD.BOLT    |
| KS2514 | SPRING PIN         |
| KS3012 | SPRING PIN         |
| KS3024 | SPRING PIN         |
| MK1901 | TRIGGER            |
| MK2001 | ADJUST LUMP        |

| COD.    | DESC.               |
|---------|---------------------|
| MK2102  | CONTACT LEVER       |
| MK2201  | COMPRESSION SPRING  |
| OA024A  | O-RING              |
| OA134A  | O-RING              |
| OB023A  | O-RING              |
| OB035A  | O-RING              |
| OB221H  | O-RING              |
| OB323A  | O-RING              |
| OG030A  | O-RING              |
| OP004A  | O-RING              |
| OP009H  | O-RING              |
| OP010A  | O-RING              |
| OP014A  | O-RING              |
| OP018H  | O-RING              |
| PN6201  | COMPRESSION SPRING  |
| UC1607W | TRIGGER ASSY.       |
| UD1104W | TRIGGER VALVE ASSY. |
| UD3603  | TRIGGER VALVE GUIDE |
| UD3701  | TRIGGER VALVE SEAT  |
| UD3804  | TRIGGER VALVE STEM  |
| UD3901  | COMPRESSION SPRING  |
| UE1501  | SEAL                |
| UL4501  | ADJUSTING WHEEL     |
| YC2401  | C-RING              |
| YG0501  | SPRING WASHER       |
| YL0508B | LOCK NUT            |
| YW0402  | FLAT WASHER         |
| YW0503  | FLAT WASHER         |